

# PWR02

## Portable waterproof speaker

### OPERATING MANUAL

Thank you for buying our ArtSound PWR02 speaker. We hope you'll enjoy it for years to come. Please read these instructions carefully and keep this manual for later reference.



### WHAT'S IN YOUR BOX

- 1x PWR02 Speaker
- 1x Type-C USB Charging Cable
- 1x AUX IN Cable
- 1x User Guide


### SAFETY INSTRUCTION

- This logo means that no naked flames, such as a candle can be placed on or near the device.
- Use this device in temperate climates only.
- This device may be used by children aged 8 years or older any by those with reduced physical, sensory or mental abilities, or those lacking experience or knowledge, provided they are correctly supervised, or if the instructions related to the use of the device have been adequately given and if the risks involved have been understood. Children must not play with this device. Children should not clean or maintain the device without supervision.
- The electrical socket must remain easily accessible if it serves as the means of disconnection.
- Always unplug the device before cleaning it.
- Clean the device with a soft dry cloth only. Never use solvents.
- Attention should be drawn to the environmental aspects of battery disposal.

- The battery (batteries or battery pack) shall not be exposed to excessive heat such as sunshine, fire or the like.

### PRODUCT DIAGRAM

- Power On / Off - Play / Pause / Reset
- Power LED
- Volume Up / Next Track
- Bluetooth / USB / Answer / Reject Call
- Volume Down / Previous Track
- Working state LED
- Broadcast
- AUX IN Jack
- Power bank / USB
- Charging port



### OPERATION

#### CHARGING YOUR SPEAKER

- Use the type-C power cord in the accessories to connect the DC 5V charger and speaker for charging.
- The orange power LED will turn on to indicate that the unit is charging. then will turn off when fully charged.

**Note:** A full charge takes approximately 3 hours.

#### POWER ON / POWER OFF

**Power on:** Press and hold the button for 2 seconds to power on the speaker. The working state LED will flash.

**Power off:** Press and hold the button for 2 seconds to power off the speaker. The working state LED will turn off.

#### PAIRING BLUETOOTH DEVICES WITH YOUR SPEAKER

The speaker will not automatically connect to a new device when power on. In order to pair your Bluetooth audio device with your Bluetooth Speaker for the first time, follow the steps below:

- Power on your speaker, the working state LED will flash in green.
- Enable Bluetooth on your devices (phone or audio device). Refer to the manufacturer's instructions for details.
- Search for Bluetooth devices and select "PWR02". If required, enter the password "0000" to confirm and complete the pairing process.
- The speaker will beep when the devices are paired. And the working state LED will turn to green.

**Note:** The speaker will power off automatically if no connection within 20 minutes.

#### DISCONNECT BLUETOOTH

Press and hold button 2 seconds, the speaker will disconnect with the Bluetooth device, others Bluetooth device will connect with the speaker.

#### BLUETOOTH MUSIC PLAYBACK

- Open the music player and select a song to play. Press the button to pause / play the music.
- Press briefly the + button to increase the volume or long press to skip to the next song.
- Press briefly the - button to decrease the volume or long press to skip to the previous song.

#### BLUETOOTH PHONE CALLS

- Click the button to answer an incoming call. Click again to end the call.
- Press and hold the button for 2 seconds to reject the call.

#### AUX IN MODE

- Use the 3.5mm audio cable in the accessories to connect the audio source equipment and speaker
- Turn on the audio source device and play music
- Press the button to play or mute the speaker.




### POWER BANK

PWR02 output 5V / 1A current through USB interface, which can charge mobile devices, such as your mobile phone, iPad, etc


### USB MODUS

Insert a USB stick, click the  button and switch to USB mode to play music.


### BROADCAST FUNCTION

1. Turn on all PWR02 speakers and make sure they are not connected to other devices (remove the AUX in cable).
2. Turn on Bluetooth on your phone/device. Search for 'Bluetooth devices', select "PWR02" and choose this speaker as master.
3. Briefly click the  button on the master speaker and hear "broadcast label" tone, briefly click the  button of d other speaker one by one, they will automatically connect to each other make.
4. Once Broadcast is connected, it will be automatically reconnected the next time it is turned on, you can clear the Broadcast by briefly pressing the  button.

### LIGHT THEME

Double click the  button when playing the music, the light theme can be changed. There are three light themes: Gradient changing light---Breathing Light---no light.

### RESET

Press and hold the  button 2 seconds to clear pairing records. (Bluetooth and TWS pairing records)

### TROUBLESHOOTING


Q: My speaker will not switch on.  
A: Please recharge it and make sure it has enough power. Plug the unit into a charger and see if the power LED indicator turn on.  
Q: Why can't I pair this speaker with other Bluetooth devices?  
A: Please check the following:  
Your Bluetooth device supports the A2DP profile.  
The speaker and your device are next to each other (within 1m).  
The speaker has connected one Bluetooth devices, if yes, you can press the button cleared and pairing new device.


### SPECIFICATION:

Bluetooth version : V5.3  
Maximum output : 25W  
Built-in power : Li-ion 7.2V 2500mAh  
SNR : 75dB  
Wireless Working Frequency : 80HZ-20KHZ  
Wireless Transmission Distance : up to 33 ft (10M)  
Powerbank : 5V / 1A  
Charging Time : about 3-4 hours  
Playback Time : up to 14 hours  
Charging : DC 5 V±0.5/2A  
Dim. (ø) 73 x (h) 191mm

### WARRANTY CONDITIONS

2 year warranty from date of purchase. The warranty is limited to the repair or replacement of the defective material insofar as this defect is a result of normal use and the device has not been damaged. Artsound is not responsible for any other costs that ensue as a result of the defect (e.g. transport). For details, please consult our general terms and conditions of sale.

 This product bears the selective sorting symbol for waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European Directive 2002/96/EC in order to be recycled or dismantled to minimize its impact on the environment. For further information, please contact your local or regional authorities.

 I, House Of Music NV, hereby declare that the type of radio equipment ARTSOUND complies with Directive 2014/53/EU. The full text of the EU Declaration of Conformity can be found at the following internet address: <http://www.artsound.be> > Support.

Disclaimer: All trademarks are the property of their respective owners. All specifications and information are subject to change without further notice. Slight variations and differences might appear between printed photos and actual product due to product enhancement. House Of Music NV - Legen Heirweg 23D, B-9890 Gavere

